

PLANCHA ALISADORA FAMILIARICESE CON SU

IMPORTANT SAFETY INSTRUCTIONS

When using electrical appliances, especially when children are present, basic safety precautions should always be followed, including the

READ ALL INSTRUCTIONS BEFORE USING KEEP AWAY FROM WATER

DANGER - Any appliance is electrically live even when the switch is off. To reduce the risk of death by electric shock:

- 1. Always unplug appliance immediately after using.
- 2. Do not use while bathing or in a shower.
- 3. Do not place or store appliance where it can fall or be pulled into a tub or sink.
- 4. Do not place in, or drop into water or other
- 5. If an appliance falls into water, unplug it immediately. Do not reach into the water.

WARNING - To reduce the risk of burns,

- 1. This appliance should never be left unat-
- on, or near children or individuals with certain disabilities
- 3. Use this appliance only for its intended use as described in this manual. Do not use attachments not recommended by the manufacturer.

llegar a las puntas. Repita estos pasos hasta 2. Abra las placas y atloje el pelo después de

yacıa jas bnuţas' manteniendo jas placas bien 4. Cierre las placas y baje la plancha lentamente

spra las placas y ponga una sección de cabello 3. Coloque la plancha cerca del cuero cabelludo,

.somitqo

pues facilita el alisado y logra resultados

Es un placer trabajar con esta nueva tecnologia,

brillantes. Gracias a ella, el alisado es más fácil

opteuer resultados profesionales, sedosos y

nuitormemente durante el peinado, para siempre

y el frizz. La cerámica distribuye el calor

ceramica tambien ayuda a controlar la estatica

táciles de limpiar después de cada uso. La

tacilmente entre las placas y que estas son muy

de salud. Notará que el cabello se desliza

qels el cabello sedoso, brillante y resplandeciente

ceràmica distribuye el calor uniformemente y

suave, lo último en tecnologia cerámica. La

cnpiertas de una capa de ceramica increibiemente

ras biacas de su nueva piancha alisadora estan

TECHOLOGIA CERAMICA

Con practica, encontrara la manera perfecta

Será necesario experimentar un poco al principio.

an cabello, puede ser necesario alisar cada

alcanzar el estilo deseado. Según la textura de

4. Do not use an extension cord to operate

5. Never operate this appliance if it has a

damaged cord or plug, if it is not working

properly, if it has been dropped or damaged,

or dropped into water. Return the appliance

to an authorized service center for examina-

6. Keep the cord away from heated surfaces.

7. Do not pull, twist, or wrap line cord around

8. Never block the air openings of the appliance

or place it on a soft surface, such as a bed

or couch, where the air openings may be blocked.

Keep the air openings free of lint, hair, and

10. Never drop or insert any object into any

11. Do not use outdoors or operate where aero-

sol (spray) products are being used or where

12. This straightener is hot when in use. Do not

13. Do not place the heated straightener di-

rectly on any surface or on the appliance

14. Before plugging in read the information about

dual voltage contained in the instruction section

power cord while it is hot or plugged in.

let heated surfaces touch eyes or bare skin.

appliance, even during storage.

Never use while sleeping.

oxygen is being administered.

opening.

tion and repair.

bara alisar su cabello facil y rapidamente.

sección de cabello varias veces.

qe sucµo bo
ı % bn|
ðaga qe esbesn
ıs o 2. Divida el cabello en secciones de 2 pulgadas

cou la piel después de encender el segundos. No permite que hagan contacto ADVERTENCIA: Las placas calentaran en

mientras este conectado. abadara. Nunca deje el aparato desatendido posición "OFF". El indicador luminoso rojo se bouda el botón de encendido/apagado en la el aparato este encendido. Para apagar el aparato, se iluminará y permanecerá encendido mientras eu la posicion "UN". El indicador luminoso rojo 240V) y ponga el botón de encendido/apagado

1. Conecte el aparato al tomacorriente (120-FUNDAMENTOS DEL ALISADO

los Estados Unidos. eucunte (uo se iucluye) para utilizarlo fuera de embargo, se deberá utilizar un adaptador de automáticamente al voltaje adecuado. Sin

Este aparato es de doble voltaje. Se adaptará

DOBLE VOLTAJE

SAVE THESE OPERATING

hold use. This unit is designed to operate at 120-240 volts AC. Use on Alternating Current

This appliance has a polarized plug (one blade is wider than the other). As a safety feature, this plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Do not attempt to defeat

DUAL VOLTAGE

seguridad.

No intente il en contra de esta funcion de completamente, comuniquese con un electricista. de corriente, invièrtela. Si aún no entrara corriente polarizada. Si no entrara en la toma eucuntar de nua soia manera en la toma de otra). Como medida de seguridad, se podrá cjavija polarizada (una pata es más ancha que El cable de este aparato está dotado de una

Uselo solamente con Corriente Alterna de 120-Este aparato fue diseñado para uso doméstico.

DE N20 INSTRUCCIONES INSTRUCCIONES **GUARDE ESTAS**

convertidor de voitaje. 17. No haga tuncionar este aparato con un

Use el agarre y los botones o perillas. 16. No toque las partes calientes de este aparato.

se vuelve muy caliente. No lo toque. 15. El cuerpo del aparato cerca de las placas

dne se eucneufts s confinnsción sufes de euchnfar 14. Lea la información relativa al doble voltaje

STRAIGHTENING BASICS

Plug the straightening iron cord into any

household outlet 120V-240V. Slide switch to

ON position. Red LED light will indicate power

is on. The iron will heat up very quickly. To turn

off, slide to OFF position. Red light will go off.

Never leave your straightening iron on and

WARNING: The straightening iron's ceramic-

coated plates will get very hot within a few

seconds and should not be placed in contact

with the skin after the straightening iron has

Start with a hair section that is 1 in, wide and

no more than ½ in. thick. Open the iron and

place a hair section between the two hot plates,

close to the scalp. Close plates over hair by

firmly squeezing the handles together. While

maintaining the tension, slowly pull the unit down

along the hair section toward the ends. At the

end of hair section, release the pressure on the

handle and allow the hair to slide out. Repeat

process on additional sections of hair until you

achieve the hair style you desire. It may be

necessary to repeat process on certain areas,

Some experience is necessary when learning

to use this straightening iron. After using the

iron several times, you will learn the ideal way

depending on the texture of your hair.

to straighten and style your hair easily.

unattended.

been turned on.

mientras este caliente o conectado. Mantenga 13. No coloque el aparato en ninguna superficie

jos olos λ is piei siejados de las superficies 12. Este aparato se vuelve muy caliente. Mantenga o donde se esté administrando oxigeno.

qouqe se esteu nasuqo broductos en aerosol (spray) 11. No lo utilice en exteriores, ni lo haga funcionar uinguna de las aberturas.

10. Nunca deje caer ni inserte un objeto en o o adormilada/o.

9. Nunca utilice el aparato mientras esté dormida/

nus csws o nu sots, donde se puedan el aparato sobre una superficie blanda, como 8. Nunca bloquee las aberturas de aire ni coloque del aparato.

7. Nunca jale, retuerza o enrolle el cable alrededor

6. Mantenga el cable alejado de las superficies

servicio autorizado para que lo examinen y estuviese danado. Regreselo a un centro de inncionado mal o que se hubiese caido o si estuviesen dañados, después de que hubiese 5. No opere este aparato si el cable o la clavija

4. No utilice una extensión con este aparato. recomendados por el fabricante. las instrucciones. Solo use accesorios

bara el cual tue disenado y solamente según 3. Use este aparato unicamente con el propósito

sopre o cerca de ninos o personas con alguna 2. Este aparato no debería ser utilizado por,

el cable alejado de las superficies calientes.

an easy-glide ceramic surface, the latest in technological advances. The ceramic even heat distribution produces the ultimate in healthy, shiny, silky looking hair. You'll find that hair glides easily over the surface of the plates as you're straightening, and that it is easier to clean styling product residue, etc. off the plates after each use. The ceramic surface also helps smooth down flyways and frizzies. As you smooth your hair, heat is evenly distributed so that the style you create has a salon-perfect, silky smooth, shiny finish. Hair also glides right through the

The new ceramic technology is a pleasure to work with, makes styling your hair easier and provides professional results.

inmediatamente. No toque el agua. 2. Si el aparato cayera al agua, desconèctelo

 $4.\ \mbox{No}$ coloque el aparato ni lo deje caer al agua

1. Nunca deje el aparato desatendido mientras

riesgo de quemaduras, electrocución, incendio

ADVERTENCIA - Para reducir el

cser o ser empujado a una banera o un 3. No colodue ni guarde el aparato donde pueda 2. No lo use en el baño o la ducha.

iatamente después de usarlo.

1. Siempre desconecte el aparato inmed-:คริเรเกิร:

. Fara reducir el riesgo de muerte o herida por bermanece bajo tension, aunque este apagado. PELIGRO – Cualquier aparato enchufado

DEL AGUA. Odalaja Ojabnetnam DE USABLO. **INSTRUCCIONES ANTES SAJ SAGOT A3J**

esté conectado.

O LIGUOSS:

pasicas de seguridad, entre las cuales las en la presencia de niños, debe tomar precauciones Siempre que use aparatos electricos, especialmente

SEGURIDAD IMPORTANTES MEDIDAS DE

GET TO KNOW YOUR CERAMIC STRAIGHTENING IRON

Ceramic-coated plates Thumb rest ON/OFF Dual voltage

INSTRUCTIONS INSTRUCTIONS

This straightening iron is intended for house-(50/60 hertz) only.

this safety feature.

This straightening iron will automatically adjust to the proper voltage. Use an adapter plug with correct configuration, prior to use in outlet.

STYLING WITH THE NEW EASY-GLIDE **CERAMIC-COATED PLATES**

The plates of your new straightening iron have plates after it's straightened.

electrocution, fire, or injury to persons:

of this manual. tended when plugged in. 15. Do not attempt to touch the housing of your 2. This appliance should not be used by. appliance near the straightening plates as it is hot when in use.

> 16. Do not touch hot surfaces of the appliance. Use the handles or knobs.

17. Do not use with a voltage converter.

CONVID



visítenos en www.conair.com

IB-10237

Para más información sobre los productos Conair, llame al 1-800-3-CONAIR o

CONAIR CORPORATION
Service Department
7475 N. Glen Harbor Blvd.
Glendale, AZ 85307
©2011 Consir Corporation

11PA119428

CENTRO DE SERVICIO

Para registrar su producto, visitenos en www.conair.com/registration.



USER MAINTENANCE

Your straightening iron is virtually maintenancefree. No lubrication is needed. Keep all vents and openings clear of dirt and dust. If cleaning becomes necessary, disconnect the unit from the power source, allow to cool and wipe exterior with a cloth. If any abnormal condition occurs, unplug the unit, allow it to cool, and return it for repair to an authorized service representative only. No repairs should be attempted by the consumer.

CAUTION


NEVER allow the power supply cord to be pulled, twisted, or severely bent. Never wrap the cord tightly around the appliance. Damage will occur at the high flex point of entry into the appliance, causing it to rupture and short. Inspect the cord frequently for damage. Stop use immediately if damage is visible or if unit stops or operates intermittently.

STORAGE

When not in use, your appliance is easy to store. Allow appliance to cool, then store out of reach of children in a safe, dry location. Do not jerk or strain cord at plug connections.

WARNING:
IF YOU THINK
THE POWER IS OFF
WHEN THE SWITCH
IS OFF,
YOU'RE WRONG.

KEEP AWAY FROM WATER



Everyone knows that electricity and water are a dangerous combination. But did you know that an electric appliance is still electrically live even if the switch is off? If the plug is in, the power is on. So when you are not using your appliances, keep them unplugged.

ALWAYS UNPLUG SMALL APPLIANCES

LIMITED TWO-YEAR WARRANTY

Conair will repair or replace, at our option, your appliance free of charge for 24 months from the date of purchase if the appliance is defective in workmanship or materials.

To obtain service under this warranty, return the defective product to the service center listed, together with your sales slip and \$5.00 for postage and handling. California residents need only provide proof of purchase and should call 1-800-3-CONAIR for shipping instructions. In the absence of a receipt, the warranty period shall be 24 months from the date of manufacture.

ANY IMPLIED WARRANTIES, OBLIGATIONS, OR LIABILITIES, INCLUDING BUT NOT LIMITED TO THE IMPLIED WARRANTY OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, SHALL BE LIMITED IN DURATION TO THE 24-MONTH DURATION OF THIS WRITTEN, LIMITED WARRANTY. Some states do not allow limitations on how long an implied warranty lasts, so the above limitations may not apply to you.

IN NO EVENT SHALL CONAIR BE LIABLE FOR ANY SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES FOR BREACH OF THIS OR ANY OTHER WARRANTY, EXPRESS OR IMPLIED, WHATSOEVER. Some states do not allow the exclusion or limitation of special, incidental, or consequential damages, so the above limitation may not apply to you. This warranty gives you specific legal rights, and you may also have other rights, which vary from state to state.

mencionadas pueden no regir para usted. Esta garantía le otorga derechos legales específicos y usted puede tener otros derechos que varian de un Estado a otro.

regir para usted.

CONAIR NO SERÁ RESPONSABLE EN MINGÚN CASO POR ALGÚN DAÑO ESPECIAL, INCIDENTAL O CONSECUENTE DEBIDO AL INCIDENTAL O CONSECUENTE DEBIDO AL ALGÚN DE ESTA O CUALQUIER ALGÚN DE ESTA O CUALGUIERO DE ESTA O CUALGUIERO DE ESTA O CUALGUIERO DE CONSECUENTE, O CONSECUE

CUALQUIER GARANTÍA, OBLIGACIÓN O RESPONSABILIDAD IMPLÍCITAS, INCLUYENDO PERO NO LIMITADAS A LA GARANTÍA IMPLÍCITA DE COMERCIABILIDAD Y APTITUD PARA UN PROPÓSITO ESPECÍFICO, ESTARÁN LIMITADAS POR LOS 24 MESES DE LA PRESENTE GARANTÍA ESCRITA. Algunos Estados no permiten limitaciones sobre la duración de una garantía implicita, de modo que las limitaciones mencionadas pueden no que las limitaciones mencionadas pueden no permiten limitacionadas pueden las limitaciones no permiten limitacionadas pueden las limitaciones no permiten limitacione no

defectos de materiales o fabricación.

Para obtener servicio técnico bajo esta garantia, regrese su aparato al Centro de Servicio indicado a confinuación, junto con su recibo de compra y un cheque o giro postal de US\$5.00 por gastos de manejo y envío. Los residentes de California sólo necesitan dar una prueba de compra y deben llamar al 1-800-3-CONAIR para recibir instrucciones de envío. En ausencia del recibo de compra, el período de garantía será de 24 meses a partir de la fecha de fabricación.


Consir reparará o remplazará (a su opción) su aparato sin cargo por un período de 24 meses a partir de la fecha de compra si presentara defectos de materiales o fabricación

GARANTIA LIMITADA DE DOS AÑOS

SIEMPRE DESENCHUFE LOS APPRATOS PEQUEÑOS

usarlos.

lodos sabemos que no se debe mezclar la electricidad y el agua. Pero ¿Sabe usted que un aparato eléctrico permanece bajo tensión aunque esté apagado? Si está conectado, hay corriente. Por lo tanto, siempre desenchule sus aparatos eléctricos después de chufe sus aparatos eléctricos después de



MANTĖNGALO ALEJADO AUĐA JED

ADVERTENCIA: SI CREE QUE NO HAY EL APARATO ESTÁ ATASA APAGADO, ESTÁ ATASA EQUIVOCADO Cuando no lo utiliza, su aparato es fácil de almacenar. Permita que enfríe y guárdelo en un lugar seco y seguro, fuera del alcance de los niños. No tironee ni retuerza el cable al nivel del enchufe y no enrolle el cable alrededor del aparato. Permita que el cable cuelgue o que la junta que lo conecta al aparato esté suelta y recta.

ALMACENAJE

MUNCA jale, tuerza ni retuerza el cable electrico. Nunca lo enrolle con fuerza alrededor del aparato. Esto podría dañar la junta flexible que lo conecta, produciendo su ruptura o un cortocircuito. Inspeccione el cable con frecuencia para asegurarse que no esté dañado. Deje de usar el aparato inmediatamente si el cable pareciera dañado, si el aparato dejara de funcionar o funcionara de manera infermitente.

PRECAUCIÓN

necesita Iubricación. Mantenga todas las aberturas libres de polvos y pelusas. Cuando sea necesario limpiarlo, desenchúfelo, permita que enfríe y limple la superficie exterior con un paño húmedo. En caso de mal funcionamiento, desconecte el aparato, permita que enfrie y regréselo a un centro de servicio autorizado. Vo intente reparar el aparato.

INSTRUCCIONES DE MANTENIMIENTO

Su aparato requiere poco mantenimiento. No



Please register this product at: www.conair.com/registration

SERVICE CENTER

CONAIR CORPORATION Service Department 7475 N. Glen Harbor Blvd. Glendale, AZ 85307 ©2011 Conair Corporation

For info on any Conair product, call: 1-800-3-CONAIR or visit us on the web at: www.conair.com

For your safety and continued enjoyment of this product, always read the instruction book carefully before using.

Instruction & Styling Guide
Model CS80

IB-10537

IB.